

West Valley Non Human Primate Module

Frequent User Egress Flow Chart

Enter Decon Room 45 and Clean Rubber Boots with Hydrochem

Enter 30C

Remove coveralls to your boots, sit on bench , remove foot from each leg of coverall and place back in boot

**Hang reusable coverall on designated hook OR
Place dirty coveralls in laundry hamper in Washroom 30D**

Remove outer pair 2nd pair of gloves(if worn) and dispose

Remove Tyvek sleeves and place on hook with coverall OR in laundry hamper on dirty side of bench

Remove safety glasses or safety shield and place on hook above your coveralls

Remove mask, bonnet and beard cover (if worn) and dispose in swing top black garbage can

Sit on bench and remove feet/shoes from boots and swing over and stand on clean side of bench

Place boots out of the way under lip of bench on the dirty side

Remove 1st pair of gloves and dispose in black swing top garbage

Enter 30A (female) or 30B (male)

Activate Privacy Interlock by pressing red button

Remove scrubs and place in cubby if clean and returning later the same day, or place in laundry

Walk through shower stall

Don street cloths

Enter 30

Wash hands at the sink
Gather personal effects and exit unit to Hallway TA -4